



How To Set Jump Stitch Settings

after upgrading your Memory Craft 11000 to a Special Edition




Step 1



Step 2

Step 3 Advance 2 pages to "Set 3" screen.



Step 4
The machine will trim the threads automatically when it stops for a thread color change. Select "Stop" to turn off auto thread cutting.

Step 5
Press the "-" or "+" key to set the minimum length of jump thread to be cut. The machine will automatically cut jump threads from 3mm to 30mm, depending on the length selected. To turn this function off, press the "+" key until "OFF" is indicated.