

Cutwork Cork Coasters

By Nancy Fiedler



With the use of Cutting Blades and designs specifically digitized for the blades, you can easily embroider and cut out these coasters for Dad with any Janome embroidery machine in no time!

Skill Level: Beginner
Sewing Time: 2 hours


Cutting Blade Info:

Cutting Blades come in a package of 4, each blade is set at a different angle to create a smooth edge as the machine cuts. You don't have to try to remember the angles. Simply insert the colored cutting blade into the needle hole of the machine when the screen indicates that color in the stitching order.



Cutwork Needles

Red: 0°
Blue: 45°
Black: 90°
Green: 135°



Janome Supplies Required:

- Any Janome embroidery machine
- Embroidery foot P
- 140mm x 140mm hoop
- High Tension Bobbin Case (yellow dot)
- Purple Tip Needle
- Janome Prewound Bobbin
- Cutting Needle Set (002VFBSET)

Fabric and Supplies needed:

- 6" square ravel free material for each coaster (manmade leather, vinyl, felt, and cork work well)
- 12" square Jenny Haskins Heat Magic for each coaster
- Temporary spray adhesive
- Embroidery Thread

Coaster embroidery design:

- For the MC15000 or Skyline S-9 use coaster.jpj.
- All other Janome embroidery machines download coaster.jef.

Embroider Design


Cutwork MC15000/Skyline S-9:

1. Place heat removable stabilizer in hoop.
2. Use temporary spray adhesive to hold 6" square in place.
3. Download coaster.jpx on a USB stick.

*Note: Settings for thread sensor and jump thread trimming function will be automatically "OFF" when using *.jpx format created with Janome Digitizer.*

*Note: Cutwork designs in *.jpx cannot be edited.*

4. Open design and embroider color 1.
5. Insert cutting blades as color indicates on screen.



6. When all cutting is completed, remove hoop from machine, clip the two or three threads to remove coaster.



7. When the cutwork design is complete, a pop-up, window will appear as a reminder to clean out the bobbin area to remove any bits of fabric/thread/stabilizer that may have fallen into the machine during cutting.



8. There is no need to remove stabilizer as this will add a moisture resistant layer on back of coaster.

Cutwork all other Janome embroidery machines:

1. Place heat removable stabilizer in hoop.
2. Use temporary spray adhesive to hold 6" square in place.
3. Download coaster.jef on a USB stick.
4. Open design and embroider color 1.

Note: Turn off upper thread sensor in Set Mode when using cutwork blades.

Note: Do not Edit a cutwork design as the cutting line may become compromised.

5. Insert cutting blades as "thread" color indicates on screen.
6. When all cutting is completed, remove hoop from machine, clip the two or three threads to remove coaster.
7. There is no need to remove stabilizer as this will add a moisture resistant layer on back of coaster.