

EZ Ruler Foot



Package Contents

1. EZ Ruler Foot
2. Instruction sheet

You Will Also Need:

- 2.5mm hex tool (This tool came with your Quilt Maker Pro machine.)

Overview

The EZ Ruler Foot has a taller profile than the standard ruler foot and provides additional stability when using rulers. The EZ Ruler Foot is also useful when quilting with high loft batting or multiple layers of batting.

To Attach the EZ Ruler Foot

1. If another Quilt Maker Pro Foot is on the mount, use the 2.5mm hex wrench to loosen the mounting screw far enough that you can slide the foot off of the mount.
2. Slide the EZ Ruler Foot onto the mount. The opening on the side of the foot lines up with the mount's screw hole. Push the EZ Ruler Foot up as far as it will go.
3. Ensure the foot is centered over the hole in the needle plate and that the needle is centered in the foot. Then fully tighten the screw with the 2.5mm hex wrench.

Tips For Using the EZ Ruler Foot

These tips apply to your Quilt Maker Pro and the EZ Ruler Foot.

- Small cutouts on the front and side of the foot help with needle visibility while quilting regardless of orientation of the hopping foot.
- When working with rulers with a standup machine, always use a ruler base (HG00454). Apply gentle three-point pressure to the ruler:
 - (1) Press ruler against any side of the EZ Ruler Foot or other hopping foot.
 - (2) Press machine against ruler.
 - (3) Press ruler against ruler base with only as much force as necessary to keep the ruler from slipping. Too much pressure will keep the machine from moving.