

Formatting your USB stick or ATA card (compact flash card) for first time use with your Memory Craft 350E:

Insert the USB stick or ATA card into your embroidery machine. Touch MODE/SET then touch the next page icon until you see the word FORMAT. Touch the YES key next to ATA card, the message “all stored data will be erased” will display, touch OK. The machine will beep when formatting is completed. When using an ATA card, insert the ATA card into the ATA card adapter, then insert that unit into the slot on the side of your embroidery machine.

When saving your embroidery files onto the USB stick or ATA card, you will need to save them in the MyDesign folder.

The maximum size USB stick or ATA card to use with this machine is 2 GB. Please note that Janome has not been able to test all brands available, so some cards may be incompatible.

