Glide Foot



PACKAGE CONTENTS

- 1. Glide Foot
- 2. Instruction sheet

YOU WILL ALSO NEED:

• 2.5mm hex tool (This tool came with your Quilt Maker Pro Quilter machine.)

OVERVIEW

The Glide Foot is a bowl-shaped foot that easily glides around appliqué, embellishments, or other dimensional elements on a quilt.

Your machine should already be fitted with the Janome Feet mount that works with the interchangeable Janome Feet. These instructions describe how to attach and use the Glide Foot.

TO ATTACH THE GLIDE FOOT

- 1. If another Janome Foot is on the mount, use the 2.5mm hex wrench to loosen the mounting screw far enough that you can slide the foot off of the mount.
- 2. Slide the Glide Foot onto the mount. The opening on the side of the foot lines up with the mount's screw hole. Push the Janome Foot up as far as it will go.
- 3. Ensure the foot is centered over the hole in the needle plate and that the needle is centered in the foot. Then fully tighten the screw with the 2.5mm hex wrench.

TIPS FOR USING THE GLIDE FOOT

- The Glide Foot is useful when quilting from the back of the machine with a pantograph. It glides over the edges of the quilt so you don't unknowingly flip the raw edges or catch lofty batting while quilting.
- The Glide Foot is also useful when quilting around appliqué designs, machine embroidery designs, rickrack, lace, or other embellishments.
- Use the Glide Foot to quilt around couched designs.
- The Glide Foot also glides over basting stitches.

