

AcuFil™ Quilting Webinar Project

Janome Supplies:

MemoryCraft 12000

AcuFil™ Tool Kit

"O" foot

"P" foot

AcuFeed Single Prong attachment and VD foot

Quilt Binding Attachment

Bobbins

Fabric and Notions

21 ½" square light green cotton

Two 6 ½" x 21 ½" dark green strips

Two 6 ½" x 33 ½" dark green strips

36" square batting

36" square backing

Four 2" x width of fabric for binding



Neutral color all-purpose thread

Artistic Olive Kimono Thread

Janome Polyester embroidery thread - Meadow

Green

Jenny Haskins Template Magic



Before starting the project print a template of Stipple1.jpg, Center.jpg, Border.jpg, and Corner.jpg.

Directions

1. Touch the Decorative Stitch Tab, select Quilting, and select stitch 2.
2. Attach the "O" foot.
3. Sew the dark green borders to the light green square and sew the four 2" strips for the binding into one long strip.


4. Baste the backing, batting and top together to create the quilt sandwich



5. Touch the toggle button to switch to embroidery.
6. Touch Set > Embroidery > Page 1/6 > One Stitch Stop > ON > OK

7. Open the Stipple1 design created in the webinar.


8. The AcuFil design appears in the Ready to Sew window. A new button is available, the Turnover Key. This allows you to rotate the design 180° when it might be necessary to turn the quilt around when handling a large quilt.



9. Touch Adjust > It may be necessary to adjust the embroidery foot height when working over seams and batting.




10. Use the template to mark the first area to be quilted in the light green area.



11. Place the quilt sandwich in the ASQ22 hoop.
12. Quilt the first section.



13. Continue across the width of the quilt.




14. Open the Center.jpg to quilt the center hooping and then open Stipple1.jpg to finish quilting the rest of the light green area.

15. Before quilting the last area, measure the remaining area. If the size is different from the original AcuFil pattern return to the AcuFil Tool and use Adjust Last Pattern Size to create an AcuFil pattern to fill the final area.




16. Draw a line in the borders 2" from the light green area to indicate the center of the borders.

17. Open Border.jpg and use the template to place the borders in the hoop. Use the jog arrows on the machine to move the needle to the center position if the placement falls below the horizontal centering line.



18. Open Corner.jpg and use the template to place the floral motif in each corner.

19. When all the quilting is completed square up the quilt so that the borders measure 4 1/2" from the seam.



20. Attach the Acufeed Flex Single Prong VD foot.
21. Select Ordinary Sewing, Multiple Zigzag #11 and sew the edge of the quilt.
22. Attach the Quilt Binding Attachment and sew the binding to the quilt.