



9-HOLE CORDING FOOT

For 9mm max. stitch width models

Sewing with 7/5 cords

Machine settings:

Stitch patterns: Multiple zigzag stitch  or Quilt stitches 

Stitch width: 7 - 8 (7 cords), 5 - 6.5 (5 cords)


Sewing speed: Low to middle

Make sure to test sewing first.




To prepare:

Use the needle threader from the bottom of the foot for threading the cords through the 7 holes () / 5 holes () of the foot.





To sew:

1. Place the fabric under the foot holder.
2. Attach the foot with inserted 7 or 5 cords.
 - * Pull the cords approximately 1 inch (2 cm) behind the presser foot.
 - * Pull the needle thread under and to the left of the foot so as not to tangle the thread with the cords.
 - * Arrange the cords in the front of the foot so as not to tangle the cords.
3. Sew while guiding the fabric and cords so as not to tangle the front cords.
 - * Decrease the stitch width if the stitch sticks out from the cord.
 - * Increase the stitch width if the cord is not firmly.



Curve Sewing:

Increase the stitch length or change the stitch pattern if the stitches are too congested.



Part No. 202506003

JANOME
Reliability by Design

janome.com





9-HOLE CORDING FOOT

For 9mm max. stitch width models

Corner sewing


Machine settings:

Stitch patterns: Multiple zigzag stitch
Stitch width: 9 (9 cords), 7 - 7.5 (7 cords), 5 - 6 (5 cords)
Sewing speed: Low to middle
Make sure to test sewing first.





To prepare:

Use the needle threader from the bottom of the foot for threading the cords through the 9 holes (●●●●●●●●●), 7 holes (○●●●●○) or 5 holes (○●●●○) of the foot.



To sew:

1. Place the fabric under the foot holder.
2. Attach the foot with inserted cords.
 - * Pull the cords approximately 1 inch (2 cm) behind the presser foot.
 - * Pull the needle thread under and to the left of the foot so as not to tangle the thread with the cords.
 - * Arrange the cords in the front of the foot so as not to tangle the cords.
3. Being careful not to get tangled in the front cords, sew until the outer edge of the cornering pattern. **3**
4. Sew the reverse stitch until the inner edge of the cornering pattern. **4**
5. Lower the needle into the fabric. Raise the presser foot slightly and turn the fabric 90°.
6. Arrange the cords. Be sure that cords are tight and there is no tangling.
7. Sew the reverse stitch until the outer edge of the cornering pattern. **7**
8. Continue sewing.
 - * Decrease the stitch width if the stitch sticks out from the cord.
 - * For 7 or 5 cords, increase the stitch width if the cord is not firmly.



Part No. 202506003

JANOME
Reliability by Design

janome.com

